

Installation guide for self-adhesive films

(with film or paper as backing liner)

The following things are needed:

- Spray bottle, tape, paper towels (not included)
- Mounting solution concentrate, item no. 020010 (not included) or alternatively 5 drops of "FROSCH- (PH) neutral cleaner" diluted in 0.5 liters water.
- Glass cleaner, item no. 020210 (not included) or an other commercially available glass cleaner
- Standard installation kit, item no. 010000 - squeegee and glass scraper blade (included)

Additional Tips:

- Install the window film with two people!
 - Do not install any film at temperatures below +6° C on the installation side.
1. Fill the spray bottle with 0.5 liters of water and add the concentrated mounting solution (30 ml), or add 5 drops of "FROSCH- (PH) neutral cleaner" (sufficient for approx. 6 to 7m² glass surface).
 2. Thoroughly clean the window or the surface to be glued with a commercially available or our glass cleaner! It is best to remove all sticky particles (e.g. paint or fly droppings) with the glass scraper blade. There must be no dirt or other residues left on the glass!
 3. **Separate the backing liner (film or paper) from the ordered self-adhesive film with the help of adhesive strips that you stick to a corner on the front and back of the film and pull them apart.** Usually the backing liner (film or paper) sticks to one adhesive strip and the actual ordered self-adhesive film to the other adhesive strip.
ATTENTION! Your film can be equipped with a (usually white) paper backing liner OR with a transparent foil backing liner, which is very thin, transparent and really there. 😊 This backing liner is non-adhesive and only serves to cover the adhesive side (like a sticker).
 4. Now hold the film you ordered while the second person peels off the backing liner (film or paper), starting from the corner and at the same time sprays the liquid solution on the exposed adhesive side. Then the window pane (surface to be glued) must also be sprayed with the liquid. Do not skimp on the liquid, the film and glass pane should be thoroughly wet.
 5. Place the ordered foil with the moistened adhesive side on the glass pane (or other Surface). The film should slide back and forth easily, otherwise spray the surface again.
 6. Now spray the other side of the foil you ordered, this will make your work with the squeegee (plastic scraper) easier.
 7. Now press the liquid with the squeegee, starting from the middle to the side edge out evenly. Make sure that there is no residual water under the film!
To avoid possible scratches, you should wrap the squeegee with a paper towel.
 8. Carefully wipe the edges and foil with a soft cloth.
If necessary, press down the edges again with the squeegee.
 9. Now let the film dry for 3 days without touching it. Wait two weeks for the first cleaning of the foil and never use hard objects (brush or blade) for cleaning.
Commercial glass cleaners can be used.