

General Care Instructions for Window Films

To ensure many years of enjoyment with your recently acquired window film, we would like to provide you with some care recommendations:

Recommended:

- During the first three weeks after installing the film, avoid cleaning it.
- You can use commercially available glass cleaning products.
- Clean the window film with soft cloths or a window squeegee.
- Ensure that your rubber squeegee and all other cleaning tools are clean.
- If the film is applied on the outside, clean it regularly at short intervals to prevent stubborn dirt from accumulating on the film's surface.
- Remove coarse dust and dirt from externally applied films using a very wet, soft window squeegee and ample clean water.
- Please exercise caution when cleaning the edges of the film.

Not recommended:

- Do not use abrasive cleaning agents.
- Never clean the windows when they are dry.
- Avoid using glass scrapers, razor blades, or Scotch-Brite pads.
- Do not use high-pressure cleaners or steam jet devices for cleaning.
- Generally, we do not recommend applying adhesive stickers on the film coating.

Cleaning:

1. Spray the window surface with a mixture of water and cleaner.
2. Use a rubber squeegee to stroke the water from top to bottom.
3. For heavily soiled areas, you can re-soak them and clean with a soft window cloth or sponge and plenty of water.
4. Spray the window again with the water-cleaner mixture and squeegee from top to bottom.

Please remember that while the surface coating of the film is scratch-resistant, it is not indestructible. Therefore, always handle it with care.